



# Comfast CF-E380AC Setup Guide

1. Download the Zappie firmware for the Comfast CF-E380AC Access Point if you haven't done so already and save it to your computer.
2. This guide assumes an understanding of POE devices, if you are unsure, please Google "PoE setup".
3. Connect the LAN port on PoE adapter to your modem or internet source, connect the PoE port to the LAN port on the Comfast device. Connect your computer using WiFi to the Comfast device. Please ensure your computer is next to the Comfast device and that the signal strength is full. This device operates in router mode and doesn't allow access over network cable to its administration interface.
4. Open your internet browser and navigate to <http://192.168.10.1/>, you'll be taken to the administrative login page. Some Comfast devices also use <http://192.168.10.254/> as their default address, try this if you are unable to login using 192.168.10.1.




5. The user is admin and the password is admin.

6. Once logged in, click “Settings” icon on the top right menu.



7. Next click on “System Tools”.



8. Under “Firmware Version” select “Choose File” and select the Zappie firmware file you downloaded earlier then click the “Upload” button.



9. The update process will take approximately 3 minutes. Do not turn off the access point.



10. On your WiFi enabled device, look for the SSID/WiFi Network called “Zappie Hotspot” and join this network. Your device should be assigned an ip address in the range of 100.88.66.X.

11. Try navigating to any non SSL domain, eg <http://www.google.com> and you should be redirected to the Zappie sign up page. Signing up is free and simply ties your access point with a Zappie operators account.